

## Zinc

**Installation:** Place the jamb bracket on the floor against the pivot jamb and align with the top track. Fasten the jamb bracket to the pivot jamb and floor with 1-1/2" (38 mm) flat head screws. Drill hole into the bottom edge of the door. Tap the assembly into the hole until the pivot is seated. Place bottom pivot into jamb bracket and reattach the top pivot into the slide glide.

**Installation :** Placer le support sur le plancher contre le montant pivotant et aligner sur le rail supérieur. Fixer le support au montant pivotant et au plancher au moyen de vis 1-1/2 po (38 mm) à tête plate. Percer un trou sur le rebord inférieur de la porte. Installer le dispositif dans le trou jusqu'à ce que le pivot soit bien en place. Insérer le pivot inférieur dans le support et ré-attacher le pivot supérieur au guide de glissière.

**Instalación:** Coloque el soporte sobre el piso contra el pivote y alinee con la pista superior. Ajuste el soporte al pivote y al piso con un tornillo de cabeza plana de 1-1/2" (38 mm). Taladrar un agujero sobre el borde inferior de la puerta. Instalar el dispositivo en el agujero hasta que el pivote esté bien en lugar. Insertar el pivote inferior en el apoyo y re-ligar el pivote superior a la guía de resbalón.



Made in China / Fabriqué en Chine / Hecho en China  
Imported by / Importé par / Importado por :

**Onward Hardware**  
Division of Richelieu Hardware Canada Ltd.  
Kitchener, Ontario, Canada N2C 0A2  
[www.onwardhardware.com](http://www.onwardhardware.com)

