
7660XR


Installation Instructions

onward

- **1.** Unplug the power door opener and disconnect it from the door.
- 2. Close garage door completely.
- **3.** Fasten "C" Clamps on both the left and right door tracks against the top side of two rollers to keep the door closed.
- 4. Unbolt hinge from door.
- 5. Feed roller into new hinge, on side closest to the edge of the door.
- 6. Place roller wheel into track and bolt hinge to door. Replace and tighten one hinge at a time.







Warning: Improper installation or door position can result in serious injury or death.

- Be sure to read and fully understand all instructions before starting any work.
- Wear eye protection.
- Disconnect power door opener from door before any other step.
- Do not remove more than one part at a time.
- Do not raise or lower without all components installed and tightly secured.
- This hardware is only intended for residential garage doors.
- All hardware, especially extension and torsion springs, is under extreme tension at all times.
- All tension must be released from springs before performing any work.
- If you are unsure if the replacement part matches the part to be replaced or if you do not understand the installation instructions, contact a professional installer.