

Installation Instructions


- 1. Unplug the power door opener and disconnect it from the door.
- 2. Close garage door completely.
- 3. Fasten "C" Clamps on both the left and right door tracks against the top side of two rollers to keep the door closed.

For top rollers, go to Step 6

- 4. Unbolt hinge from door.
- 5. Feed new roller into hinge, on side closest to the edge of the door. Place roller wheel into track and bolt hinge to door. Replace and tighten one hinge at a time.

6. For Top Rollers only

- a. Install an additional "C" Clamp in door track so top section of door does not rotate down when the bracket is removed.
- b. Replace brackets or rollers one at a time, moving "C" Clamp or locking pliers to prevent door section from pivoting. Install roller into bracket and feed roller into track. Fasten bracket to door and use adjusting bolt on bracket to snug door against jamb.



Warning: Improper installation or door position can result in serious injury or death.

- Be sure to read and fully understand all instructions before starting any work.
- Wear eye protection.
- · Disconnect power door opener from door before any other step.
- Do not remove more than one part at a time.
- Do not raise or lower without all components installed and tightly secured.
- This hardware is only intended for residential garage doors.
- · All hardware, especially extension and torsion springs, is under extreme tension at all times.
- All tension must be released from springs before performing any work.
- If you are unsure if the replacement part matches the part to be replaced or if you do not understand the installation instructions, contact a professional installer.